

FIG.1




FIG.2




FIG.3




FIG.4




FIG.5A




FIG.5B




FIG.6A




FIG.6B




FIG.7

No.	STANDARD MESSAGES
1	OK
2	NG
3	THANK YOU
4	ONE MORE TIME
5	5 SECONDS TO PHOTOGRAPHY
6	4 · 3 · 2 · 1
7	SAY CHEESE!
8	10 SECONDS TO PHOTOGRAPHY. GET READY.
9	MESSAGE FROM CAMERA 1B

FIG.8

< DIGITAL CAMERA 1A > < DIGITAL CAMERA 1B,1C,1D >




FIG.9A

DIGITAL CAMERA 1A DSCA0001.JPG, DSCA0002.JPG, DSCA0003.JPG...
DIGITAL CAMERA 1B DSCA0001.JPG, DSCA0002.JPG, DSCA0003.JPG...
DIGITAL CAMERA 1C DSCA0001.JPG, DSCA0002.JPG, DSCA0003.JPG...
DIGITAL CAMERA 1D DSCA0001.JPG, DSCA0002.JPG, DSCA0003.JPG...

FIG.9B

DIGITAL CAMERA 1A DSCA0001.JPG, DSCA0005.JPG, DSCA0009.JPG...
DIGITAL CAMERA 1B DSCA0002.JPG, DSCA0006.JPG, DSCA0010.JPG...
DIGITAL CAMERA 1C DSCA0003.JPG, DSCA0007.JPG, DSCA0011.JPG...
DIGITAL CAMERA 1D DSCA0004.JPG, DSCA0008.JPG, DSCA0012.JPG...

FIG.10

DSCA0001.JPG	(01, F602_1A, M, c\pict\)
DSCA0002.JPG	(01, F400_1B, S1, c\pict\)
DSCA0003.JPG	(01, F400_1C, S2, c\pict\)
DSCA0004.JPG	(01, F601_1D, S3, c\pict\)
DSCA0005.JPG	(02, F602_1A, M, c\pict\)
DSCA0006.JPG	(02, F400_1B, S1, c\pict\)
DSCA0007.JPG	(02, F400_1C, S2, c\pict\)
DSCA0008.JPG	(02, F601_1D, S3, c\pict\)
DSCA0009.JPG	(03, F602_1A, M, c\pict\)
DSCA0010.JPG	(03, F400_1B, S1, c\pict\)
DSCA0011.JPG	(03, F400_1C, S2, c\pict\)
DSCA0012.JPG	(03, F601_1D, S3, c\pict\)
•	
•	
•	
•	
•	

FIG.11




FIG.12




FIG.13

<DIGITAL CAMERA 1A>

<CAMERA SERVER>

<DIGITAL CAMERA 1B,1C,1D>

START

NO
SHUTTER BUTTON
PRESSED COMPLETELY?

S21

S22

S25

PERFORM
PHOTOGRAPHY

PERFORM
PHOTOGRAPHY

ADMINISTER
IMAGE PROCESS

ADMINISTER
IMAGE PROCESS

TRANSMIT
IMAGE DATA

TRANSMIT
IMAGE DATA

S26

S26

ADMINISTER
IMAGE PROCESS

ADMINISTER
IMAGE PROCESS

TRANSMIT
IMAGE DATA

TRANSMIT
IMAGE DATA

S27

TRANSMIT
IMAGE DATA

S28

S28

RECEIVE
IMAGE DATA

RECEIVE
IMAGE DATA

S29

S29

STORE IMAGE
DATA UPDATA

STORE IMAGE
DATA UPDATA

S30

S30

TRANSMIT IMAGE DATA
TO DIGITAL CAMERA 1A

TRANSMIT IMAGE DATA
TO DIGITAL CAMERA 1A

END

FIG.14




FIG.15




FIG.16




FIG.17




FIG. 18




FIG.19




FIG.20




FIG.21




FIG.22




FIG.23

DISPLAY WINDOW NUMBER	WINDOW SIZE
1	400×300
2	240×180
3	240×180
4	240×180
5	200×150
6	200×150

FIG.24A




FIG.24B




FIG.24C




FIG.24D




FIG.25




FIG.26




FIG.27




FIG.28




FIG.29




FIG.30




FIG.31

